



**(Division of Acme Mfg. Corp.)
6532 Tower Lane
Claremore, OK 74019**

**(800) 647-8671 Toll Free
(918) 266-3091 Fax**

MISTOP MAINTENANCE

Mistop Moisture Eliminators require minimal maintenance.

Visual inspection is recommended periodically. Scale or clogging will impair performance.

If scale or clogging occurs, remove the Mistop Section(s) and flush with steam or water. Flushing should not have sufficient force to dislodge media panels. Scale removal may require a vinegar or detergent application followed by a rinsing.